Warning

1. Important safety instructions. Read and understand all instructions prior to installation. Save these instructions for future reference.

Your satisfaction with our product and service is important to us. If you have any questions, comments or concerns, please contact us at 800.882.9110 or visit our website at www.transtector.com. We look forward to continuing to serve your protection needs.

Thank you for your recent purchase of our surge protection solution.

800.882.9110 | 208.635.6400 | www.transtector.com



Installation Instructions

FSP 4000 MC



Installation Instructions

- 1. The FSP 4000 MC Series is designed to protect one or two pairs of wires. It must be installed as close to the protected equipment as possible.
- 2. All connections are "straight through" with no series impedance (i.e. Line A is connected to Line A, Line B is connected to Line B, etc.).
- 3. The connections labeled "Shield 1" and "Shield 2" are pass through and have no suppression or connection to ground.
- 4. The "EQUIP GND" connection should be kept as short as possible and utilize the largest gauge wire possible.

